

#### 1.Re-Set NeoCharge

WiFi Setup on the NeoCharge is exposed for the first 5 minutes after a reboot.

In order to expose the WiFi Setup, either un-plug the NeoCharge and plug it back in, or power cycle it by turning off the breaker and turning it back on.

### **2.Connect to NeoSetup** Open the Wi-Fi Setting page on your mobile device.

Select the NeoSetup Wi-Fi Network.


SSID: NeoSetup Password: password



N? Ar	ndroid System	Ö ू 🖌 🖹 46% 🖡
Sign NeoS	in to Wi-Fi network eetup	
	Use Wi-Fi	<b></b>
•	NeoSetup Tap here to sign in to network	ŝ
•	RooCharge Saved	•
•	MySpectrumWiFid0-2G	۵
•	HP-Print-D0-Officejet 4630	

# **4.Tap the Sign in to Network Notification** If prompted, check the box to connect even through there is no network connection

If you don't see an option to sign in, open your browser and go to the IP address **10.10.0.1**  Sign in to NeoSetup



# Tap on Manual Setup

:

### 6:35 👬 🗖 🎯

🛈 👧 📲 📉 45% 🛔	
---------------	--

:

# Sign in to NeoSetup

10.10.0.1

# Wi-Fi

MANUAL CONNECT								
ADD (HIDDEN) SSID								
OR C	CHOOSE A NETWORK							
Ro	ooCharge	€?						
М	ySpectrumWiFid0-2G	<b>₽</b> ?						
М	ySpectrumWiFib8-2G	<b>≙</b>						
Q	uieran	<b>≙</b> (;						
Н	P-Print-D0-Officejet 4630	((.						
М	yCharterWiFid0-2G	<b>₽</b> (;						
Ν	ETGEAR37	<b>₽</b> 🙃						
М	ySpectrumWiFi50-2G	<b>₽</b> (;						
М	ySpectrumWiFi98-2G	<b>₽</b> 🙃						
М	01_2.4	<b>≙</b>						

## 5.Select your WiFi network

Choose the WiFi network you would like to connect NeoCharge to

6:35 🗱 🖪 🔘

🛈 🔊 🕫 🕍 🔪 45% 🛔

:

Sign in to NeoSetup

10.10.0.1

# Enter Password

PASSWORD FOR ROOCHARGE

Password

Ca	ance	el								Un	hic	le			Joi	n	
1	2		3		4		5		6		7		8		9		0
q	w		e		r		t		y		u		i		0		р
а		S		d		f		g		h		j		k		I	
仑		Z		x		С		v		b		n		m		<b>(</b> 2	<
?123	}															-	<b>&gt;</b>

# 6.Enter your Password

Use the Unhide button if you want to preview your password

If the password is in-correct, you will be reverted to **Step 5** 

6:36 👬 💎 🗖 🔘

🛈 📢 📲 🚺 45%

:


Sign in to NeoSetup

Please wait...

**CONNECTING TO ROOCHARGE** 

7.Wait while NeoCharge connects to the network

NeoCharge may fail to connect to the WiFi network, in which case you will be reverted to **Step 4** and will need to try again.



OK	

6:36 🗱 🗖 🎯

🔞 🐋 📲 📉 45% 🛔

:

Sign in to NeoSetup

Please wait...

**CONNECTING TO ROOCHARGE** 

#### Success!

OK

#### 8.Connection Success:

The Success message will be displayed to indicate that NeoCharge was able to successfully connect to Wi-Fi.

In some cases, you may not see this message, but the LEDs on the NeoCharge will turn blue for 5 seconds to indicate a successful connection.

To double check if NeoCharge has connected to the internet, open your Wi-Fi networks list, and NeoSetup should no longer be visible.

#### 9.Firmware Update:

Once the NeoCharge connects to WiFi, if there's a WiFi update available, it will try to automatically download the latest firmware from the NeoCharge Servers.

You may hear the NeoCharge Click on and off a few times during the process, but once the update is complete, the Indicator Lights will turn blue for 5 seconds and the NeoCharge will reboot and stop clicking. As a safety feature, the NeoCharge will disable your EV Charger connected to the Secondary side until the update is complete.